





STACK ME UP BOOKCASE – 2 SHELF










PARTS INCLUDED:

- (A) Long Frame – 2pcs
- (B) Short Frame – 2pcs
- (C) Divider (without holes) – 1pc
- (D) Back Panel – 1pc

TOOLS REQUIRED:

- Philips Screwdriver
- 
- (Not included)

HARDWARE LIST:


| | | |
|--|--|---|
|  (E) Allen Key – 1x |  (F) Long Bolt 1/4"x25mm – 10x |  (G) Short Bolt 1/4"x9mm – 6x |
|  (H) Spring Washer 1/4" – 8x |  (I) Flat Washer 1/4" – 8x |  (J) End Cap – 8x |
|  (K) Wood Screw 3.5x15mm – 27x | | |

PRE-ASSEMBLY:


- For your safety and ease, assembly by two adults is recommended.
- Please read all instructions before beginning assembly. The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- Remove all parts and hardware from box and lay out on a carpeted or scratch-free work surface. The shipping box provides an ideal work surface. Do not dispose of any contents until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists to identify and separate each of the pieces included prior to starting assembly.
- Note: DO not fully tighten the bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.
- Do not use power drill as it may cause cracking.

ASSEMBLY INSTRUCTIONS:

1. Remove all furniture parts from box and put them on a soft, scratch free surface such as a carpet or rug. Slide a Spring Washer (H) and a Flat Washer (I) onto each Long Bolt (F). Attach (2) Short Frame (B) and Divider (C) to the Long Frame (A) as shown below (Use dowels and holes to align parts). Use (2) Long Bolts with washers to secure the Long Frame (A) to each Short Frame (B) using Allen Key (E) as shown below.




2. Turn the assembled piece upright. Align and attach the remaining Long Frame (A) onto the assembled piece. Use (2) Long Bolts with washers to secure the long frame to each Short Frame (B) using Allen Key (E) as shown below.




3. Attach Back Panel (D) to back side of the assembled piece. Secure the back panel to the frame with (24) Wood Screws (K) and secure the back panel to the divider with the remaining (3) Wood Screws (O).

Use Short Bolts (G) and End Cap (J) to fill the connecting holes on each Long/Short Frame panels.



4. When stacking and connecting bookcases to each other, insert Long Bolts (F) through corresponding holes located on Top/Bottom/Side Panels and use End Cap (J) from other end to secure bookcases to each other.



CARE INSTRUCTIONS:

- Dust often using a clean, soft, dry lint-free cloth.
- Blot spills immediately, and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish.